



FC 71 Flow Cell Operator's Manual



The model FC 71 flow cell consists of a polycarbonate or anodized aluminum flow channel. A glass viewing port allows reflected light microscopy of biofilm growth on coupons and in the flow channel.

Viewing Windows

The viewing window consists of a no. 2, 24mm x 60mm cover slip. The glass viewing window is held in place by an anodized aluminum cover plate. The cover plate also compresses the silicone rubber gasket material to provide a leak-proof flow cell.

Coupons

The flow channel has been recessed to accept one 6mm x 25mm x 2mm rectangular coupon, three 10mm diameter x 2mm thick disc coupons, or two 0.5in diameter x 0.15in thick (same coupons as used in the CDC, RDR, and Bio-inLine Biofilm Reactors, shown above).

1. Flow Cell Assembly and Operation

It is very important that the flow cells be assembled properly to provide a leak-proof seal. The flow cell is designed for a **maximum flow rate of 3.5 mL/minute**. Flow rates in excess of 3.5mL/minute could damage the flow cell or cause leaks.

Disassembly

1. Remove the ten (10) screws holding the cover plates in place.
2. Remove the cover plate (most likely the gaskets and glass viewing ports will remain with the flow cell).
3. Carefully remove the glass cover slip from the gasket material. If the cover slip is broken, remove and discard the cover slip.
4. Carefully clean the gasket surface, removing all glass and other debris. **It is very important no residual glass or other material be left on the gasket surface.**
5. Clean the flow channel surfaces using water and laboratory detergent. **Do not scrub or mar the glass/flow channel mating surfaces.**

Assembly

1. Carefully position the clean gasket on the cover plate. Align the screw holes in the gasket and the cover plate (it helps to wet the gasket, so it sticks to the cover plate).
2. Carefully position a clean, unbroken cover slip in the slight recess in the flow channel (the cover slip must be properly aligned into the recess to prevent breakage or leaking during and after assembly). **Improper placement will result in leaking around the cover slip and/or cover slip breakage.**
3. Insert two screws through the cover plate and gasket. These screws will help align the cover plate while it is lowered onto the flow channel and cover slip. Carefully place the cover plate with gasket onto the flow channel, ensuring the cover slip maintains proper positioning.
4. Place the screws into the beveled screw holes and tighten evenly around the perimeter, alternating sides as the screws are tightened. **It is important that the screw holes in the cover plate align with the holes in the gasket material.** Improper alignment may result in leaking.
5. Install tubing on the tube ports and pump liquid through the flow cell to confirm a liquid tight seal.

2. Autoclaving Instructions

The FC 71 Flow Cell is autoclavable up to 121°C, at 20 minutes. Using temperatures or times past what is suggested may cause unnecessary stress to some materials and will not be covered under warranty. Polycarbonate plastic will degrade with a numerous autoclave cycles and may eventually require replacement.

BioSurface Technologies recommends always using the slow (liquid) exhaust option. The screws holding the cover plates on the flow cell should be loosened to allow for material expansion when autoclaving the polycarbonate flow cell. Tubing connected to the flow cell should allow free exchange of steam with the surrounding environment. BST recommends using a gas permeable material to cover the tubing ends such as autoclave paper instead of a gas-impermeable material, such as tin foil (for the polycarbonate flow cell, slowly tighten the screws as the flow cell cools or wait until the flow cell is completely cooled before tightening the screws). Align all tubing connected to the flow cell to minimize stress on the flow cell fittings.

3. Spare Parts

Included with the flow cell:

- Spare screws (4-40, stainless steel)
- Spare gasket
- Additional cover slips (no. 2, 24mm x 60mm)

With proper care, the gaskets should be re-useable for numerous experimental evaluations. The spare gaskets provided require removal of the clear protective polymer sheeting from both sides of the gasket prior to installation. The gasket material is 0.020 inches thick silicone rubber. Other materials may be used.

4. Troubleshooting

Problem: Glass viewing ports keep breaking

Solution:

- Check to ensure the glass is properly positioned in the recessed slot.
- Ensure the gasket surfaces and flow channel mating surfaces are total free of debris.

Problem: Flow cell leaks

Solution:

- Tighten screws further to compress gasket.
- Make sure flow channel and hose barbs are free and clear of obstructions.
- Make sure glass viewing ports are not cracked or broken.
- Check gasket for rips or tears. Clear of all debris. Replace, as necessary.
- High flow rates may create too much back pressure to contain leakage. Reduce flow rate. **The flow cell is designed for a maximum flow rate of 3.5 ml/minute.**
- Glass slide well depth is machined to a precise depth to accommodate 1.00 mm thickness glass slides. A tolerance of +/- 0.02 mm glass slide thickness variation is acceptable. If the flow cell is leaking from the glass slide side of the flow cell, try a thicker glass slide to generate a seal.

5. Flow Cell Ancillary Equipment List

NOTE: BioSurface Technologies does not sell or supply the ancillary equipment described below. This or comparable equipment is required to complete the reactor system set-up. Please check with your local vendors for availability and current pricing. Equipment listed is not recommended equipment, but an aid to help you identify compatible equipment.

Pump: There are many types of peristaltic pumps available, and you may opt for alternative types and pump head configurations (multi-channel versus single channel, higher/lower rpm range, etc.). Depending on what you need to add to the reactor during operation, you may require more than 1 pump or a multi-head pump (media for growth and biofilm treatment chemical for some duration that may require an additional pump).

- **L/S Variable Speed Modular Drive Pump system (1-100 RPM)**
(Cole-Parmer P/N EW-07557-10; 90-230 VAC CE certified)
- **Ismatec Minicartridge Pump Heads for Masterflex L/S Drives**
(Cole-Parmer P/N EW-07623-10)
 - Has 8 channels; will accommodate 8 influent lines. Alternate pump heads are available for 2 or 4 channel systems.
 - Accepts size 13 tubing.

Tubing and Fittings: The tubing you choose depends on the chemical compatibility, gas permeability, wear resistance in peristaltic pumps, and pricing. You must choose the tubing that best fits your needs. C-Flex tubing (listed below) is similar to silicone tubing but has a low gas-permeability compared to silicone. If gas-permeability is not an issue, standard silicone tubing is acceptable.

- **Size 13 tubing 25' C-Flex:**
(Cole Parmer P/N [HV-06424-13](#))
 - For use with the Ismatec pump head cartridges, connected to the size 16 tubing using adapters.
- **Size 13/16 tubing adapters** (connect size 13 to size 16 tubing)
(Cole Parmer P/N EW-30622-22)
- **Masterflex, C-Flex (50 A), L/S 16, 25 ft.** (Cole Parmer P/N EW-06424-16)
 - Accepts the 1/8" barbed connectors (3.2 mm connectors).
 - To connect to the media supply reservoir and to the flow cell connections.
- **Male Luer Lock x 1/8" barb –Polypropylene (included with standard flow cell system)** (Cole Parmer P/N A-30504-10)
- **Masterflex, C-Flex (50 A), 1/4" ID x 7/16" OD, 25 ft**
(Cole Parmer P/N EW-06424-72)
 - A few lengths and adapters to get from the carboy to the smaller diameter tubing, and as a siphon tube inside the carboy.
- **Nylon 1/4" x 1/8" adapter** (Cole Parmer P/N EW-30622-28)
 - Needed to get from the 3/16" or 1/4" ID to the 1/8" tubing.

Carboy: The carboy should be selected based on experiment needs and may be larger or smaller than what is suggested below. Ported lids can be purchased from suppliers, but standard lids are easily converted to ported lids using the following fittings or similar.

- **Cole-Parmer Heavy-Duty PP Carboy with Shoulder Handle, 10 L**
(Cole Parmer P/N EW-62507-10)
- **Filling / Venting ports for carboy lid - 1/4" tubing**

(Cole Parmer P/N EW-06259-10)

- Each reservoir vessel will require this port for the bacterial air vent.
- **Filling / Venting ports for carboy lid - 1/2" tubing**
(Cole Parmer P/N EW-06259-00)
- **Bacterial vent for media and waste reservoirs**
Any 0.22-0.45 um filter will work; can use pre-sterilized filters and mount on the vessels immediately after autoclaving.

Suggested Ancillary Equipment Suppliers:

Cole Parmer: 800-323-4340 (www.coleparmer.com)

Fisher Scientific: 1 800-766-7000 (www.fishersci.com)